(1) Checking the Hard Drive

PART 3.1

Applications

↓

Utilities

↓

Disk Utility

↓

Select a Disk

↓

First Aid

↓

Click "VERIFY DISK"

↓

- **DISK VERIFIED**
- **DISK NEEDING REPAIR**

↓

REPAIR DISK

↓

- **COULD NOT REPAIR**
- **DISK REPAIRED**

ONCE A WEEK?

↓

BOOT COMPUTER FROM ORIGINAL INSTALLATION/RESTORE DISK [WHILE BOOTING HOLD THE "C" KEY DOWN]

↓

INSTALLER MENU (Pre 10.3) Or "DISK UTILITIES" DROP DOWN MENU

↓

SELECT THE DISK (LEFT HAND PANE)

↓

FIRST AID

↓

DISK REPAIR

↓

- **DISK REPAIRED**
- **OFF TO THE TECHNICIAN**